



RECOMMENDATIONS FOR OPTIMAL BRAKE SETUP FOR ROLF PRIMA ALUMINUM RIMS

1. Use Rolf Prima brake pads for best performance.
2. Toe-In Brake Pads 1mm. When the forward most tip of the pad first contacts the rim, there should be 1mm space at the back of the pad.

